

IGNITION SYSTEM ON-VEHICLE INSPECTION

IG04X-02

NOTICE:

"Cold" and "Hot" in these sentences express the temperature of the coils themselves. "Cold" is from -10°C (14°F) to 50°C (122°F) and "Hot" is from 50°C (122°F) to 100°C (212°F).

1. INSPECT IGNITER AND SPARK TEST


Check that the spark occurs.

- (1) Remove the ignition coil. (See page IG-6)
- (2) Remove the spark plug.
- (3) Install the spark plug to the ignition coil, and connect the ignition coil connector.
- (4) Ground the spark plug.
- (5) Check if spark occurs while engine is being cranked.

NOTICE:

To prevent excess fuel being injected from the injectors during this test, do not crank the engine for more than 5 - 10 seconds at a time.

If a spark does not occur, do the test as follows:




2. INSPECT SPARK PLUGS

NOTICE:

- ◆ Never use a wire brush for cleaning.
- ◆ Never attempt to adjust the electrode gap on used a spark plug.
- ◆ Spark plugs should be replaced every 100,000 km (60,000 miles).

(a) Remove the ignition coils assemblies.
(See page IG-6)




(b) Inspect the electrode.
Using a megger (insulation resistance meter), measure the insulation resistance.

Standard correct insulation resistance:
10 MΩ or more

If the resistance is less than specified, proceed to step (c).

HINT:

If a megger is not available, the following simple method of inspection provides fairly accurate results.



Simple Method:


- ◆ Quickly race the engine 5 times to 4,000 rpm.
- ◆ Remove the spark plug.
- ◆ Visually check the spark plug.
If the electrode is dry ... OK
If the electrode is wet ... Proceed to step (d).
- ◆ Reinstall the spark plug.

(c) Using a 16 mm plug wrench, remove the 6 spark plugs.
(d) Visually check the spark plug for thread damage and insulator damage.

If abnormal, replace the spark plug.

Recommended spark plug:

DENSO made	PK20R11
NGK made	BKR6EP11



(e) Inspect the electrode gap.

Maximum electrode gap for used spark plug:
1.3 mm (0.051 in.)

If the gap is greater than maximum, replace the spark plug.

Correct electrode gap for new spark plug:
1.1 mm (0.043 in.)

NOTICE:

If adjusting the gap of a new spark plug, bend only the base of the ground electrode. Do not touch the tip. Never attempt to adjust the gap on the used plug.



- (f) Clean the spark plugs.
If the electrode has traces of wet carbon, allow it to dry and then clean with a spark plug cleaner.


Air pressure: Below 588 kPa (6 kgf/cm², 85 psi)

Duration: 20 seconds or less

HINT:

If there are traces of oil, remove it with gasoline before using the spark plug cleaner.

- (g) Using a 16 mm plug wrench, reinstall the 6 spark plugs.
Torque: 18 N·m (180 kgf·cm, 13 ft·lbf)
- (h) Reinstall the ignition coils assemblies.
(See page IG-7)



3. INSPECT IGNITION COILS


- (a) Remove the No.3 timing belt cover.
- (b) Disconnect the ignition coil connectors.
- (c) Using an ohmmeter, measure the resistance between the terminals.

Primary coil resistance:

Cold	0.54 - 0.84 Ω
Hot	0.68 - 0.98 Ω

If the resistance is not as specified, replace the ignition coil.

- (d) Reconnect the ignition coil connectors.
- (e) Reinstall the No.3 timing belt cover.




4. INSPECT CAMSHAFT POSITION SENSORS

- (a) Disconnect the camshaft position sensor connectors.
- (b) Using an ohmmeter, measure the resistance between terminals.

Resistance:

Cold	835 - 1,400 Ω
Hot	1,060 - 1,645 Ω

If the resistance is not as specified, replace the camshaft position sensor.



- (c) Reconnect the camshaft position sensor connectors.
- 5. INSPECT CRANKSHAFT POSITION SENSOR**
- (a) Remove the No.2 air tube for the CAC.
- (b) Disconnect the crankshaft position sensor connector.
- (c) Using an ohmmeter, measure the resistance between terminals.

Resistance:


Cold	835 - 1,400 Ω
Hot	1,060 - 1,645 Ω


If the resistance is not as specified, replace the sensor.

- (d) Reconnect the crankshaft position sensor connector.
- (e) Reinstall the No.2 air tube for the CAC.

IGNITION COIL COMPONENTS

IG04Y-01






REMOVAL

1. REMOVE NO.3 TIMING BELT COVER
2. REMOVE PCV HOSES
3. DISCONNECT IGNITION COIL CONNECTORS
4. REMOVE BRACKET AND IGNITION COILS ASSEMBLIES

Remove the 2 bolts and 2 ignition coils assembly.


Torque: 8.8 N·m (90 kgf·cm, 78 in.-lbf)



5. REMOVE IGNITION COILS FROM BRACKET
 - (a) Remove the rubber boot from the ignition coil.
 - (b) Remove the 2 screws and ignition coil.

CAMSHAFT POSITION SENSOR COMPONENTS

IG051-01



REMOVAL

1. DISCONNECT IAC VALVE CONNECTOR
2. DISCONNECT AIR HOSE FROM IAC VALVE
3. REMOVE ENGINE HANGER

Remove the 2 bolts, ground strap and engine hanger.


Torque: 39 N·m (400 kgf·cm, 29 ft·lbf)

4. DISCONNECT CAMSHAFT POSITION SENSOR CONNECTORS

5. REMOVE CAMSHAFT POSITION SENSORS


Remove the 4 bolts, 2 camshaft position sensors and 2 gaskets.

Torque: 8.8 N·m (90 kgf·cm, 78 in.-lbf)




CRANKSHAFT POSITION SENSOR COMPONENTS

IG054-01




S00337




REMOVAL


1. **REMOVE GENERATOR**
(See page [CH-8](#))
2. **DISCONNECT CRANKSHAFT POSITION SENSOR CONNECTOR**
 - (a) Disconnect the sensor connector from the bracket.
 - (b) Disconnect the sensor connector from the wiring connector.
3. **REMOVE CRANKSHAFT POSITION SENSOR**
 - (a) Disconnect the wire clamp from the cylinder block.
 - (b) Remove the bolt and crankshaft position sensor.
Torque: 8.8 N·m (90 kgf·cm, 78 in.-lbf)




STARTER COMPONENTS

ST04C-02





Magnetic Switch Assembly



P18674
P25130

N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

Z18832